



eWoodpecker Electronics Company



----- www.ewoodpecker.com

WayTronic Teams



Front



Back

Back



USB Power

Power On|Off



Lift Side

Lift Side

Right Side

Right Side

	Station	Means
Switch	Button	Power off
	Middle	Middle Volume
	Top	Maxi Volume
Play LED indicator	Off	Turn off Power Stop Play
	On	Playing
A Key	Short Press	Pre - Sound
	Long Press	Switch A B play mode A Mode, flash one time B mode: Flash twice
B Key	Short Press	Next Sound
	Long Press	Coping mode: Copy sound from TF card into Built-in Flash Memory.
Mini USB Power	Connecting power adapter or PC computer for DC5V	Supporting Power

1. Small size case with high quality, Playing MP3 format files with beautiful sound;
2. Two volume options ;
3. Using PIR body motion sensor to trigger, distance can be detector up to 4 meters.
4. No stop play while it playing ;
5. 16M SPI-flash as memory in it. Duration sound will be about 10 - 16 minutes.
- 6: A key: upper one, B key: next one.
- 7: A,B play mode: A: loop all sound one by one; B mode: play single sound
- 8: Voice can be updated through TF card;
- 9: 3 battery-powered,
- 10: built-in 8 ohm 0.5 watt speakers.

How to update Sound

1. MP3 Format.

Note: Support 16Kbps ~ 320Kbps bit rate MP3 files

2. Saving MP3 files in TF Card

3. Put the TF card into TF Port

4. Keep the power on

5. Push B key for a long time . When the led light flashing then can remove your finger.

After cope, you can remove your TF card. At this time. The sound in TF card update in Main Unit.